



Schurter

3-101-429

Tau Wae:

3-101-429

Kaihanga / Waitohu:

Schurter

Whakaahuatanga hua

SWITCH PUSH SPST-NO 100MA 42V

Ngā Rauemi:

3-101-429.pdf

RoHS Tūnga

Whakahaerehia te kore utu / RoHS

Waehere Stock

2704 pcs stock

Tuhinga mai i

Hong Kong

Te Ara Tuhi

DHL/Fedex/TNT/UPS/EMS

TONO MO TE WHAKAHUA

Ko te whakaahua he tohu. Tirohia nga korero mo nga taipitopito hua.

Ngā whakaaturanga o 3-101-429

TAU WAE	3-101-429
KAIHANGA	Schurter
WHAKAAHUATANGA	SWITCH PUSH SPST-NO 100MA 42V
WHAKAHAERE TOKO WHAKAHAERE / ROHS TŪNGA	Whakahaerehia te kore utu / RoHS
HE RAHINGA KEI TE WĀTEA	2704 pcs
PEPA RARAUNGA	3-101-429.pdf
WHAKAAETANGA NGAOHIKO - DC	60V
WHAKAAETANGA NGAOHIKO - AC	42V
MOMO	Capacitive, Illuminated
KĀHUA WHAKAMUTUNGA	Wire Leads
WHAKAWHITI MAHINGA	Off-Mom
RAUPAPA	CPS
PIHANGA WHAKAPAE PAEPAE	Circular - 22.10mm Dia
PACKAGING	Bulk
ĒTAHI INGOA	486-3372 CPS22-NO00A10-SNCSNCF-RIRGBVAR-W0000-S
TAE MAHI	-40°C ~ 60°C
MOMO TAE	Panel Mount, Front
TAUMATA WHAKAARO MOE (MSL)	1 (Unlimited)
TE MAHI MOMO	-
WHAKAHAERE TOKO WHAKAHAERE / ROHS TŪNGA	Lead free / RoHS Compliant
TIAKI INGOA	IP67 - Dust Tight, Waterproof
WHAKAKAMAHI WHAKAKUKU (NOMINAL)	5 ~ 28 VDC
MOMO WHAKAMARAMA, TAE	LED, Red/Green/Blue
NGĀ ĀHUATANGA	-
TE ORANGA RAWA	-
WHAKAAHUATANGA TAIPITOPITO	Pushbutton Switch SPST-NO Capacitive, Illuminated Panel Mount, Front
WHAKATAURANGA ONAMATA	100mA (AC/DC)
TAE - KAIHOAHOA / KAPORO	Silver
TAKAHANGA	SPST-NO
MOMO KAIHOKO	Round, Button, Flush

Ngā tūtohu e hāngai ana

Schurter 3-101-429	3-101-429 Kaiwhiwhi	3-101-429 Kaiwhakarato
3-101-429 Utu	3-101-429 Pikitia	3-101-429 Whakaahua
3-101-429 PDF Datasheet	3-101-429 Download Datasheet	Tuhinga 3-101-429
3-101-429 Stock	Hokona 3-101-429	Hokona Schurter 3-101-429
Schurter 3-101-429	Schurter Kaiwhakarato	Schurter Kaiwhiwhi
Schurter 3-101-429	Schurter Inc. 3-101-429	

Ngā Hua e hāngai ana

<p>3-101-425 Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 2276 pcs</p> <p>RFQ</p>	<p>3-101-687 Kaihanga: Schurter Whakaahuatanga: 6600-5, MOUNTING: SNAP-IN, 2.0 M I roto i te taonga: 48113 pcs</p> <p>RFQ</p>
<p>3-101-689 Kaihanga: Schurter Whakaahuatanga: 6600-5, MOUNTING: SNAP-IN, 2.0 M I roto i te taonga: 64265 pcs</p> <p>RFQ</p>	<p>3-101-424 Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NO 100MA 42V I roto i te taonga: 2690 pcs</p> <p>RFQ</p>
<p>3-101-428 Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 2386 pcs</p> <p>RFQ</p>	<p>3-101-430 Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 2781 pcs</p> <p>RFQ</p>
<p>3-101-431 Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 2697 pcs</p> <p>RFQ</p>	<p>3-101-427 Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NO 100MA 42V I roto i te taonga: 2804 pcs</p> <p>RFQ</p>
<p>3-101-426 Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 2737 pcs</p> <p>RFQ</p>	<p>3-101-685 Kaihanga: Schurter Whakaahuatanga: 6600-5, MOUNTING: SNAP-IN, 2.0 M I roto i te taonga: 39862 pcs</p> <p>RFQ</p>
<p>3-101-423 Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 2971 pcs</p> <p>RFQ</p>	<p>3-101-686 Kaihanga: Schurter Whakaahuatanga: 6600-5, MOUNTING: SNAP-IN, 2.0 M I roto i te taonga: 46825 pcs</p> <p>RFQ</p>

