

Schurter

CPS16-NO00A10-SNCCWTWF-AIOWTVAR-W1073-S

Tau Wae:	CPS16-NO00A10-SNCCWTWF-AIOWTVAR-W1073-S
Kaihanga / Waitohu:	Schurter
Whakaahuatanga hua	SWITCH PUSH SPST-NO 100MA 42V
Ngā Rauemi:	CPS16-NO00A10-SNCCWTWF-AIOWTVAR-W1073-S.pdf
RoHS Tūnga	Whakahaerehia te kore utu / RoHS
Waehe Stock	5430 pcs stock
Tuhinga mai i	Hong Kong
Te Ara Tuhi	DHL/Fedex/TNT/UPS/EMS

TONO MO TE WHAKAHUA

Ko te whakaahua he tohu. Tirohia nga korero mo nga taipitopito hua.

Ngā whakaaturanga o CPS16-NO00A10-SNCCWTWF-AIOWTVAR-W1073-S

TAU WAE	CPS16-NO00A10-SNCCWTWF-AIOWTVAR-W1073-S
KAIHANGA	Schurter
WHAKAAHUATANGA	SWITCH PUSH SPST-NO 100MA 42V
WHAKAHAERE TOKO WHAKAHAERE / ROHS TŪNGA	Whakahaerehia te kore utu / RoHS
HE RAHINGA KEI TE WĀTEA	5430 pcs
PEPA RARAUNGA	CPS16-NO00A10-SNCCWTWF-AIOWTVAR-W1073-S.pdf
WHAKAAETANGA NGAOHIKO - DC	60V
WHAKAAETANGA NGAOHIKO - AC	42V
MOMO	Capacitive, Illuminated
KĀHUA WHAKAMUTUNGA	Wire Leads
WHAKAWHITI MAHINGA	Off-Mom
RAUPAPA	CPS
PIHANGA WHAKAPAE PAEPAE	Circular - 16.10mm Dia
PACKAGING	Bulk
TAE MAHI	-40°C ~ 60°C
MOMO TAE	Panel Mount, Front
TAUMATA WHAKAARO MOE (MSL)	1 (Unlimited)
TE MAHI MOMO	-
WHAKAHAERE TOKO WHAKAHAERE / ROHS TŪNGA	Lead free / RoHS Compliant
TIAKI INGOA	IP67 - Dust Tight, Waterproof
WHAKAKAMAHI WHAKAKUKU (NOMINAL)	5 ~ 28 VDC
MOMO WHAKAMARAMA, TAE	LED, White
NGĀ ĀHUATANGA	Ceramic Actuator, Finger Guide, RESET Symbol
TE ORANGA RAWA	-
WHAKAAHUATANGA TAIPITOPITO	Pushbutton Switch SPST-NO Capacitive, Illuminated Panel Mount, Front
WHAKATAURANGA ONAMATA	100mA (AC/DC)
TAE - KAIHOAHOA / KAPORO	Clear (White Filter/Diffuser)
TAKAHANGA	SPST-NO
MOMO KAIHOKO	Round, Button, Flush

Ngā tūtohu e hāngai ana

Schurter CPS16-NO00A10-SNCCWTWF-AIOWTVAR-W1073-S	CPS16-NO00A10-SNCCWTWF-AIOWTVAR-W1073-S Kaiwhiwhi	CPS16-NO00A10-SNCCWTWF-AIOWTVAR-W1073-S Kaiwhakarato
CPS16-NO00A10-SNCCWTWF-AIOWTVAR-W1073-S Utu	CPS16-NO00A10-SNCCWTWF-AIOWTVAR-W1073-S Pikitia	CPS16-NO00A10-SNCCWTWF-AIOWTVAR-W1073-S Whakaahua
CPS16-NO00A10-SNCCWTWF-AIOWTVAR-W1073-S PDF Datasheet	CPS16-NO00A10-SNCCWTWF-AIOWTVAR-W1073-S Download Datasheet	Tuhinga CPS16-NO00A10-SNCCWTWF-AIOWTVAR-W1073-S
CPS16-NO00A10-SNCCWTWF-AIOWTVAR-W1073-S Stock	Hokona CPS16-NO00A10-SNCCWTWF-AIOWTVAR-W1073-S	Hokona Schurter CPS16-NO00A10-SNCCWTWF-AIOWTVAR-W1073-S
Schurter CPS16-NO00A10-SNCCWTWF-AIOWTVAR-W1073-S	Schurter Kaiwhakarato	Schurter Kaiwhiwhi
Schurter CPS16-NO00A10-SNCCWTWF-AIOWTVAR-W1073-S	Schurter Inc. CPS16-NO00A10-SNCCWTWF-AIOWTVAR-W1073-S	

Ngā Hua e hāngai ana

<p>CPS16-NO00A10-SNCCWTWF-AIOWYVAR-W1001-S</p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NO 100MA 42V I roto i te taonga: 5161 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px;">RFQ</p>	<p>CPS16-NO00A10-SNCCWTWF-AIOWTVAR-W1067-S</p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NO 100MA 42V I roto i te taonga: 4262 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px;">RFQ</p>
<p>CPS16-NO00A10-SNCCWTWF-AIOWTVAR-W1074-S</p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NO 100MA 42V I roto i te taonga: 4512 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px;">RFQ</p>	<p>CPS16-NO00A10-SNCCWTWF-AIOWTVAR-W1072-S</p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NO 100MA 42V I roto i te taonga: 5495 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px;">RFQ</p>
<p>CPS16-NO00A10-SNCCWTWF-AIOWTVAR-W1069-S</p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NO 100MA 42V I roto i te taonga: 2986 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px;">RFQ</p>	<p>CPS16-NO00A10-SNCCWTWF-AIOWTVAR-W1070-S</p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NO 100MA 42V I roto i te taonga: 5123 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px;">RFQ</p>
<p>CPS16-NO00A10-SNCCWTWF-AIOWYVAR-W0000-S</p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NO 100MA 42V I roto i te taonga: 4178 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px;">RFQ</p>	<p>CPS16-NO00A10-SNCCWTWF-AIOWTVAR-W1075-S</p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NO 100MA 42V I roto i te taonga: 4247 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px;">RFQ</p>
<p>CPS16-NO00A10-SNCCWTWF-AIOWTVAR-W1071-S</p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NO 100MA 42V I roto i te taonga: 6014 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px;">RFQ</p>	<p>CPS16-NO00A10-SNCCWTWF-AIOWTVAR-W1068-S</p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NO 100MA 42V I roto i te taonga: 7014 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px;">RFQ</p>
<p>CPS16-NO00A10-SNCCWTWF-AIOWTVAR-W1076-S</p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NO 100MA 42V I roto i te taonga: 5469 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px;">RFQ</p>	<p>CPS16-NO00A10-SNCCWTWF-AIOWTVAR-W1077-S</p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NO 100MA 42V I roto i te taonga: 7006 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px;">RFQ</p>