

Schurter

SCHURTE
ELECTRONIC COMPONE

CPS16-LA00A10-SNCCWTNF-AI0GRVAR-W1073-S

| | |
|---------------------|---|
| Tau Wae: | CPS16-LA00A10-SNCCWTNF-AI0GRVAR-W1073-S |
| Kaihanga / Waitohu: | Schurter |
| Whakaahuatanga hua | SWITCH PUSHBUTTON SPST 100MA 42V |
| Ngā Rauemi: | CPS16-LA00A10-SNCCWTNF-AI0GRVAR-W1073-S.pdf |
| RoHs Tūnga | Whakahaerehia te kore utu / RoHS |
| Waehe Stock | 6151 pcs stock |
| Tuhinga mai i | Hong Kong |
| Te Ara Tuhi | DHL/Fedex/TNT/UPS/EMS |

TONO MO TE WHAKAHUA

Ko te whakaahua he tohu. Tirohia nga korero mo nga taipitopito hua.

Ngā whakaaturanga o CPS16-LA00A10-SNCCWTNF-AI0GRVAR-W1073-S

| | |
|---|---|
| TAU WAE | CPS16-LA00A10-SNCCWTNF-AI0GRVAR-W1073-S |
| KAIHANGA | Schurter |
| WHAKAAHUATANGA | SWITCH PUSHBUTTON SPST 100MA 42V |
| WHAKAHAERE TOKO WHAKAHAERE / ROHS TŪNGA | Whakahaerehia te kore utu / RoHS |
| HE RAHINGA KEI TE WĀTEA | 6151 pcs |
| PEPA RARAUNGA | CPS16-LA00A10-SNCCWTNF-AI0GRVAR-W1073-S.pdf |
| WHAKAAETANGA NGAOHIKO - DC | 60V |
| WHAKAAETANGA NGAOHIKO - AC | 42V |
| MOMO | Capacitive, Illuminated |
| KĀHUA WHAKAMUTUNGA | Wire Leads |
| WHAKAWHITI MAHINGA | Off-On |
| RAUPAPA | CPS |
| PIHANGA WHAKAPAE PAEPAE | Circular - 16.10mm Dia |
| PACKAGING | Bulk |
| TAE MAHI | -40°C ~ 60°C |
| MOMO TAE | Panel Mount, Front |
| TAUMATA WHAKAARO MOE (MSL) | 1 (Unlimited) |
| TE MAHI MOMO | - |
| WHAKAHAERE TOKO WHAKAHAERE / ROHS TŪNGA | Lead free / RoHS Compliant |
| TIAKI INGOA | IP67 - Dust Tight, Waterproof |
| WHAKAKAMAHI WHAKAKUKU (NOMINAL) | 5 ~ 28 VDC |
| MOMO WHAKAMARAMA, TAE | LED, Green/Red |
| NGĀ ĀHUATANGA | Ceramic Actuator, RESET Symbol |
| TE ORANGA RAWA | - |
| WHAKAAHUATANGA TAIPITOPITO | Pushbutton Switch SPST Capacitive, Illuminated Panel Mount, Front |
| WHAKATAURANGA ONAMATA | 100mA (AC/DC) |
| TAE - KAIHOAHOA / KAPORO | Clear (White Filter/Diffuser) |
| TAKAHANGA | SPST |
| MOMO KAIHOKO | Round, Button, Flush |

Ngā tūtohu e hāngai ana

| | | |
|---|--|---|
| Schurter CPS16-LA00A10-SNCCWTNF-AI0GRVAR-W1073-S | CPS16-LA00A10-SNCCWTNF-AI0GRVAR-W1073-S Kaiwhiwhi | CPS16-LA00A10-SNCCWTNF-AI0GRVAR-W1073-S Kaiwhakarato |
| CPS16-LA00A10-SNCCWTNF-AI0GRVAR-W1073-S Utu | CPS16-LA00A10-SNCCWTNF-AI0GRVAR-W1073-S Pikitia | CPS16-LA00A10-SNCCWTNF-AI0GRVAR-W1073-S Whakaahua |
| CPS16-LA00A10-SNCCWTNF-AI0GRVAR-W1073-S PDF Datasheet | CPS16-LA00A10-SNCCWTNF-AI0GRVAR-W1073-S Download Datasheet | Tuhinga CPS16-LA00A10-SNCCWTNF-AI0GRVAR-W1073-S |
| CPS16-LA00A10-SNCCWTNF-AI0GRVAR-W1073-S Stock | Hokona CPS16-LA00A10-SNCCWTNF-AI0GRVAR-W1073-S | Hokona Schurter CPS16-LA00A10-SNCCWTNF-AI0GRVAR-W1073-S |
| Schurter CPS16-LA00A10-SNCCWTNF-AI0GRVAR-W1073-S | Schurter Kaiwhakarato | Schurter Kaiwhiwhi |
| Schurter CPS16-LA00A10-SNCCWTNF-AI0GRVAR-W1073-S | Schurter Inc. CPS16-LA00A10-SNCCWTNF-AI0GRVAR-W1073-S | |

Ngā Hua e hāngai ana

| | |
|--|--|
| <p>CPS16-LA00A10-SNCCWTNF-AI0GRVAR-W1069-S Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 4218 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px; font-weight: bold;">RFQ</p> | <p>CPS16-LA00A10-SNCCWTNF-AI0GRVAR-W1067-S Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 4558 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px; font-weight: bold;">RFQ</p> |
| <p>CPS16-LA00A10-SNCCWTNF-AI0GRVAR-W1074-S Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 6468 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px; font-weight: bold;">RFQ</p> | <p>CPS16-LA00A10-SNCCWTNF-AI0GRVAR-W1071-S Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 5196 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px; font-weight: bold;">RFQ</p> |
| <p>CPS16-LA00A10-SNCCWTNF-AI0GRVAR-W1068-S Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 6445 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px; font-weight: bold;">RFQ</p> | <p>CPS16-LA00A10-SNCCWTNF-AI0GRVAR-W1070-S Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 6095 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px; font-weight: bold;">RFQ</p> |
| <p>CPS16-LA00A10-SNCCWTNF-AI0GRVAR-W1077-S Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 3612 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px; font-weight: bold;">RFQ</p> | <p>CPS16-LA00A10-SNCCWTNF-AI0GRVAR-W1075-S Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 3385 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px; font-weight: bold;">RFQ</p> |
| <p>CPS16-LA00A10-SNCCWTNF-AI0GWVAR-W1001-S Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 2906 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px; font-weight: bold;">RFQ</p> | <p>CPS16-LA00A10-SNCCWTNF-AI0GRVAR-W1076-S Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 3877 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px; font-weight: bold;">RFQ</p> |
| <p>CPS16-LA00A10-SNCCWTNF-AI0GRVAR-W1072-S Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 4468 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px; font-weight: bold;">RFQ</p> | <p>CPS16-LA00A10-SNCCWTNF-AI0GWVAR-W0000-S Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 4847 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px; font-weight: bold;">RFQ</p> |