

SparkFun

COM-09136

Tau Wae:

Kaihanga / Waitohu:

Whakaahuatanga hua

Ngā Rauemi:

Waehere Stock

Tuhinga mai i

Te Ara Tuhi

COM-09136

SparkFun

ARCADE JOYSTICK

 COM-09136.pdf

5349 pcs stock


Hong Kong

DHL/Fedex/TNT/UPS/EMS

TONO MO TE WHAKAHUA

Ko te whakaahua he tohu. Tirohia nga korero mo nga taipitopito hua.













Ngā whakaaturanga o COM-09136

TAU WAE	COM-09136
KAIHANGA	SparkFun
WHAKAAHUATANGA	ARCADE JOYSTICK
WHAKAHAERE TOKO WHAKAHAERE / ROHS TŪNGA	
HE RAHINGA KEI TE WĀTEA	5349 pcs
PEPA RARAUNGA	 COM-09136.pdf
TUHINGA O MUA	-
MOMO	Joystick, 2 - Axis
KĀHUA WHAKAMUTUNGA	Quick Connect - 0.250" (6.3mm)
WHAKAWHITI MAHINGA	8-Way Directional
RAUPAPA	-
PIHANGA WHAKAPAE PAEPAE	-
WHAKAPUTA	Digital (Mechanical Switch)
ĒTAHI INGOA	1568-1482 9136
TAE MAHI	-
TE KAHA MAHI	-
MOMO TAE	Panel Mount
TE MAHI MOMO	100,000 Cycles
TIAKI INGOA	-
NGA MAHI, TETAHI	1 Pushbutton
NGĀ ĀHUATANGA	Arcade Style
TE ORANGA RAWA	100,000 Cycles
WHAKAAHUATANGA TAIPITOPITO	Joystick, 2 - Axis Digital (Mechanical Switch) Output
WHAKATAURANGA ONAMATA	-
WHAKAAETANGA MEA	-
WHAKAUTU WHAKAMUTUNGA	-
MOMO KAIHOKO	Joystick

Ngā tūtohu e hāngai ana

SparkFun COM-09136	COM-09136 Kaiwhiwhi	COM-09136 Kaiwhakarato
COM-09136 Utu	COM-09136 Pikitia	COM-09136 Whakaahua
COM-09136 PDF Datasheet	COM-09136 Download Datasheet	Tuhinga COM-09136
COM-09136 Stock	Hokona COM-09136	Hokona SparkFun COM-09136
SparkFun COM-09136	SparkFun Kaiwhakarato	SparkFun Kaiwhiwhi
SparkFun COM-09136	SparkFun Electronics COM-09136	

Ngā Hua e hāngai ana

 <p>COM-08914 Kaihanga: SparkFun Whakaahuatanga: MAGNET RING - 3/16" I roto i te taonga: 90491 pcs</p> <p>RFQ</p>	 <p>COM-08890 Kaihanga: SparkFun Whakaahuatanga: MAGNET DISK - 0.709" I roto i te taonga: 110380 pcs</p> <p>RFQ</p>
 <p>COM-09336 Kaihanga: SparkFun Whakaahuatanga: SWITCH PUSHBUTTON SPDT 3A 120V I roto i te taonga: 36440 pcs</p> <p>RFQ</p>	 <p>COM-09032 Kaihanga: SparkFun Whakaahuatanga: JOYSTICK 10K OHM 2 AXIS TH I roto i te taonga: 23967 pcs</p> <p>RFQ</p>
 <p>COM-09277 Kaihanga: SparkFun Whakaahuatanga: BUTTON PAD 2X2 - BREAKOUT PCB I roto i te taonga: 18187 pcs</p> <p>RFQ</p>	 <p>COM-09182 Kaihanga: SparkFun Whakaahuatanga: ARCADE JOYSTICK SHORT HANDLE I roto i te taonga: 6583 pcs</p> <p>RFQ</p>
 <p>COM-09000 Kaihanga: SparkFun Whakaahuatanga: ADDRESS LED MODULE I2C RGB I roto i te taonga: 3661 pcs</p> <p>RFQ</p>	 <p>COM-09181 Kaihanga: SparkFun Whakaahuatanga: SWITCH PUSHBUTTON SPDT RED I roto i te taonga: 7890 pcs</p> <p>RFQ</p>
 <p>COM-08892 Kaihanga: SparkFun Whakaahuatanga: MP3 AND MIDI CODEC VS1053B I roto i te taonga: 4551 pcs</p> <p>RFQ</p>	 <p>COM-09308 Kaihanga: SparkFun Whakaahuatanga: BLACKBERRY TRACKBALL I roto i te taonga: 2750 pcs</p> <p>RFQ</p>
 <p>COM-09120 Kaihanga: SparkFun Whakaahuatanga: KNOB RIBBED PLASTIC I roto i te taonga: 100785 pcs</p> <p>RFQ</p>	 <p>COM-09337 Kaihanga: SparkFun Whakaahuatanga: SWITCH PUSHBUTTON SPDT 3A 120V I roto i te taonga: 38208 pcs</p> <p>RFQ</p>