

Schurter

CPS22-LA00A10-SNCSNCWF-RI0CYVAR-W1077-S

Tau Wae:	CPS22-LA00A10-SNCSNCWF-RI0CYVAR-W1077-S
Kaihanga / Waitohu:	Schurter
Whakaahuatanga hua	SWITCH PUSHBUTTON SPST 100MA 42V
Ngā Rauemi:	CPS22-LA00A10-SNCSNCWF-RI0CYVAR-W1077-S.pdf
RoHS Tūnga	Whakahaerehia te kore utu / RoHS
Waehe Stock	5244 pcs stock
Tuhinga mai i	Hong Kong
Te Ara Tuhi	DHL/Fedex/TNT/UPS/EMS

TONO MO TE WHAKAHUA

Ko te whakaahua he tohu. Tirohia nga korero mo nga taipitopito hua.

Ngā whakaaturanga o CPS22-LA00A10-SNCSNCWF-RI0CYVAR-W1077-S

TAU WAE	CPS22-LA00A10-SNCSNCWF-RI0CYVAR-W1077-S
KAIHANGA	Schurter
WHAKAAHUATANGA	SWITCH PUSHBUTTON SPST 100MA 42V
WHAKAHAERE TOKO WHAKAHAERE / ROHS TŪNGA	Whakahaerehia te kore utu / RoHS
HE RAHINGA KEI TE WĀTEA	5244 pcs
PEPA RARAUNGA	CPS22-LA00A10-SNCSNCWF-RI0CYVAR-W1077-S.pdf
WHAKAAETANGA NGAOHIKO - DC	60V
WHAKAAETANGA NGAOHIKO - AC	42V
MOMO	Capacitive, Illuminated
KĀHUA WHAKAMUTUNGA	Wire Leads
WHAKAWHITI MAHINGA	Off-On
RAUPAPA	CPS
PIHANGA WHAKAPAE PAEPAE	Circular - 22.10mm Dia
PACKAGING	Bulk
TAE MAHI	-40°C ~ 60°C
MOMO TAE	Panel Mount, Front
TAUMATA WHAKAARO MOE (MSL)	1 (Unlimited)
TE MAHI MOMO	-
WHAKAHAERE TOKO WHAKAHAERE / ROHS TŪNGA	Lead free / RoHS Compliant
TIAKI INGOA	IP67 - Dust Tight, Waterproof
WHAKAKAMAHI WHAKAKUKU (NOMINAL)	5 ~ 28 VDC
MOMO WHAKAMARAMA, TAE	LED, Cyan
NGĀ ĀHUATANGA	Finger Guide, Power Symbol
TE ORANGA RAWA	-
WHAKAAHUATANGA TAIPITOPITO	Pushbutton Switch SPST Capacitive, Illuminated Panel Mount, Front
WHAKATAURANGA ONAMATA	100mA (AC/DC)
TAE - KAIHOAHOA / KAPORO	Silver
TAKAHANGA	SPST
MOMO KAIHOKO	Round, Button, Flush

Ngā tūtohu e hāngai ana

Schurter CPS22-LA00A10-SNCSNCWF-RI0CYVAR-W1077-S	CPS22-LA00A10-SNCSNCWF-RI0CYVAR-W1077-S Kaihiwhi	CPS22-LA00A10-SNCSNCWF-RI0CYVAR-W1077-S Kaiwhakarato
CPS22-LA00A10-SNCSNCWF-RI0CYVAR-W1077-S Utu	CPS22-LA00A10-SNCSNCWF-RI0CYVAR-W1077-S Pikitia	CPS22-LA00A10-SNCSNCWF-RI0CYVAR-W1077-S Whakaahua
CPS22-LA00A10-SNCSNCWF-RI0CYVAR-W1077-S PDF Datasheet	CPS22-LA00A10-SNCSNCWF-RI0CYVAR-W1077-S Download Datasheet	Tuhinga CPS22-LA00A10-SNCSNCWF-RI0CYVAR-W1077-S
CPS22-LA00A10-SNCSNCWF-RI0CYVAR-W1077-S Stock	Hokona CPS22-LA00A10-SNCSNCWF-RI0CYVAR-W1077-S	Hokona Schurter CPS22-LA00A10-SNCSNCWF-RI0CYVAR-W1077-S
Schurter CPS22-LA00A10-SNCSNCWF-RI0CYVAR-W1077-S	Schurter Kaiwhakarato	Schurter Kaihiwhi
Schurter CPS22-LA00A10-SNCSNCWF-RI0CYVAR-W1077-S	Schurter Inc. CPS22-LA00A10-SNCSNCWF-RI0CYVAR-W1077-S	

Ngā Hua e hāngai ana

<p>CPS22-LA00A10-SNCSNCWF-RI0GBVAR-W1002-S</p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 4568 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 2px 5px; font-weight: bold;">RFQ</p>	<p>CPS22-LA00A10-SNCSNCWF-RI0GBVAR-W1004-S</p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 6271 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 2px 5px; font-weight: bold;">RFQ</p>
<p>CPS22-LA00A10-SNCSNCWF-RI0GBVAR-W1005-S</p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 7023 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 2px 5px; font-weight: bold;">RFQ</p>	<p>CPS22-LA00A10-SNCSNCWF-RI0GBVAR-W1001-S</p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 6471 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 2px 5px; font-weight: bold;">RFQ</p>
<p>CPS22-LA00A10-SNCSNCWF-RI0GBVAR-W0000-S</p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 3188 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 2px 5px; font-weight: bold;">RFQ</p>	<p>CPS22-LA00A10-SNCSNCWF-RI0CYVAR-W1072-S</p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 4183 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 2px 5px; font-weight: bold;">RFQ</p>
<p>CPS22-LA00A10-SNCSNCWF-RI0CYVAR-W1075-S</p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 2811 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 2px 5px; font-weight: bold;">RFQ</p>	<p>CPS22-LA00A10-SNCSNCWF-RI0CYVAR-W1074-S</p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 5031 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 2px 5px; font-weight: bold;">RFQ</p>
<p>CPS22-LA00A10-SNCSNCWF-RI0CYVAR-W1073-S</p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 5378 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 2px 5px; font-weight: bold;">RFQ</p>	<p>CPS22-LA00A10-SNCSNCWF-RI0CYVAR-W1076-S</p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 4610 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 2px 5px; font-weight: bold;">RFQ</p>
<p>CPS22-LA00A10-SNCSNCWF-RI0GBVAR-W1003-S</p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 3244 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 2px 5px; font-weight: bold;">RFQ</p>	<p>CPS22-LA00A10-SNCSNCWF-RI0CYVAR-W1071-S</p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 2715 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 2px 5px; font-weight: bold;">RFQ</p>