

Schurter

ELECTRONIC COMPONE

CPS16-LA00A10-SNCSNCF-RI0YLVAR-W1077-S

Tau Wae:	CPS16-LA00A10-SNCSNCF-RI0YLVAR-W1077-S
Kaihanga / Waitohu:	Schurter
Whakaahuatanga hua	SWITCH PUSHBUTTON SPST 100MA 42V
Ngā Rauemi:	CPS16-LA00A10-SNCSNCF-RI0YLVAR-W1077-S.pdf
RoHS Tūnga	Whakahaerehia te kore utu / RoHS
Waehere Stock	4594 pcs stock
Tuhinga mai i	Hong Kong
Te Ara Tuhi	DHL/Fedex/TNT/UPS/EMS

TONO MO TE WHAKAHUA

Ko te whakaahua he tohu. Tirohia nga korero mo nga taipitopito hua.

Ngā whakaaturanga o CPS16-LA00A10-SNCSNCF-RI0YLVAR-W1077-S

TAU WAE	CPS16-LA00A10-SNCSNCF-RI0YLVAR-W1077-S
KAIHANGA	Schurter
WHAKAAHUATANGA	SWITCH PUSHBUTTON SPST 100MA 42V
WHAKAHAERE TOKO WHAKAHAERE / ROHS TŪNGA	Whakahaerehia te kore utu / RoHS
HE RAHINGA KEI TE WĀTEA	4594 pcs
PEPA RARAUNGA	CPS16-LA00A10-SNCSNCF-RI0YLVAR-W1077-S.pdf
WHAKAAETANGA NGAOHIKO - DC	60V
WHAKAAETANGA NGAOHIKO - AC	42V
MOMO	Capacitive, Illuminated
KĀHUA WHAKAMUTUNGA	Wire Leads
WHAKAWHITI MAHINGA	Off-On
RAUPAPA	CPS
PIHANGA WHAKAPAE PAEPAE	Circular - 16.10mm Dia
PACKAGING	Bulk
TAE MAHI	-40°C ~ 60°C
MOMO TAE	Panel Mount, Front
TAUMATA WHAKAARO MOE (MSL)	1 (Unlimited)
TE MAHI MOMO	-
WHAKAHAERE TOKO WHAKAHAERE / ROHS TŪNGA	Lead free / RoHS Compliant
TIAKI INGOA	IP67 - Dust Tight, Waterproof
WHAKAKAMAHI WHAKAKUKU (NOMINAL)	5 ~ 28 VDC
MOMO WHAKAMARAMA, TAE	LED, Yellow
NGĀ ĀHUATANGA	Power Symbol
TE ORANGA RAWA	-
WHAKAAHUATANGA TAIPITOPITO	Pushbutton Switch SPST Capacitive, Illuminated Panel Mount, Front
WHAKATAURANGA ONAMATA	100mA (AC/DC)
TAE - KAIHOAHOA / KAPORO	Silver
TAKAHANGA	SPST
MOMO KAIHOKO	Round, Button, Flush

Ngā tūtohu e hāngai ana

Schurter CPS16-LA00A10-SNCSNCF-RI0YLVAR-W1077-S	CPS16-LA00A10-SNCSNCF-RI0YLVAR-W1077-S Kaiwhiwhi	CPS16-LA00A10-SNCSNCF-RI0YLVAR-W1077-S Kaiwhakarato
CPS16-LA00A10-SNCSNCF-RI0YLVAR-W1077-S Utu	CPS16-LA00A10-SNCSNCF-RI0YLVAR-W1077-S Pikitia	CPS16-LA00A10-SNCSNCF-RI0YLVAR-W1077-S Whakaahua
CPS16-LA00A10-SNCSNCF-RI0YLVAR-W1077-S PDF Datasheet	CPS16-LA00A10-SNCSNCF-RI0YLVAR-W1077-S Download Datasheet	Tuhinga CPS16-LA00A10-SNCSNCF-RI0YLVAR-W1077-S
CPS16-LA00A10-SNCSNCF-RI0YLVAR-W1077-S Stock	Hokona CPS16-LA00A10-SNCSNCF-RI0YLVAR-W1077-S	Hokona Schurter CPS16-LA00A10-SNCSNCF-RI0YLVAR-W1077-S
Schurter CPS16-LA00A10-SNCSNCF-RI0YLVAR-W1077-S	Schurter Kaiwhakarato	Schurter Kaiwhiwhi
Schurter CPS16-LA00A10-SNCSNCF-RI0YLVAR-W1077-S	Schurter Inc. CPS16-LA00A10-SNCSNCF-RI0YLVAR-W1077-S	

Ngā Hua e hāngai ana

<div style="border: 1px solid #ccc; padding: 5px;"> <p style="margin: 0;">CPS16-LA00A10-SNCSNCF-RI0YLVAR-W1076-S</p> <p style="font-size: 8px; margin: 0;">Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 5112 pcs</p> <p style="text-align: center; background-color: #e91e63; color: white; padding: 2px; font-weight: bold; font-size: 10px;">RFQ</p> </div>	<div style="border: 1px solid #ccc; padding: 5px;"> <p style="margin: 0;">CPS16-LA00A10-SNCSNCF-RI0YMMVAR-W1001-S</p> <p style="font-size: 8px; margin: 0;">Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 6972 pcs</p> <p style="text-align: center; background-color: #e91e63; color: white; padding: 2px; font-weight: bold; font-size: 10px;">RFQ</p> </div>
<div style="border: 1px solid #ccc; padding: 5px;"> <p style="margin: 0;">CPS16-LA00A10-SNCSNCF-RI0YMMVAR-W1004-S</p> <p style="font-size: 8px; margin: 0;">Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 3703 pcs</p> <p style="text-align: center; background-color: #e91e63; color: white; padding: 2px; font-weight: bold; font-size: 10px;">RFQ</p> </div>	<div style="border: 1px solid #ccc; padding: 5px;"> <p style="margin: 0;">CPS16-LA00A10-SNCSNCF-RI0YMMVAR-W1003-S</p> <p style="font-size: 8px; margin: 0;">Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 2782 pcs</p> <p style="text-align: center; background-color: #e91e63; color: white; padding: 2px; font-weight: bold; font-size: 10px;">RFQ</p> </div>
<div style="border: 1px solid #ccc; padding: 5px;"> <p style="margin: 0;">CPS16-LA00A10-SNCSNCF-RI0YLVAR-W1074-S</p> <p style="font-size: 8px; margin: 0;">Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 5814 pcs</p> <p style="text-align: center; background-color: #e91e63; color: white; padding: 2px; font-weight: bold; font-size: 10px;">RFQ</p> </div>	<div style="border: 1px solid #ccc; padding: 5px;"> <p style="margin: 0;">CPS16-LA00A10-SNCSNCF-RI0YLVAR-W1071-S</p> <p style="font-size: 8px; margin: 0;">Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 4978 pcs</p> <p style="text-align: center; background-color: #e91e63; color: white; padding: 2px; font-weight: bold; font-size: 10px;">RFQ</p> </div>
<div style="border: 1px solid #ccc; padding: 5px;"> <p style="margin: 0;">CPS16-LA00A10-SNCSNCF-RI0YMMVAR-W1005-S</p> <p style="font-size: 8px; margin: 0;">Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 5615 pcs</p> <p style="text-align: center; background-color: #e91e63; color: white; padding: 2px; font-weight: bold; font-size: 10px;">RFQ</p> </div>	<div style="border: 1px solid #ccc; padding: 5px;"> <p style="margin: 0;">CPS16-LA00A10-SNCSNCF-RI0YMMVAR-W0000-S</p> <p style="font-size: 8px; margin: 0;">Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 2717 pcs</p> <p style="text-align: center; background-color: #e91e63; color: white; padding: 2px; font-weight: bold; font-size: 10px;">RFQ</p> </div>
<div style="border: 1px solid #ccc; padding: 5px;"> <p style="margin: 0;">CPS16-LA00A10-SNCSNCF-RI0YLVAR-W1072-S</p> <p style="font-size: 8px; margin: 0;">Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 6964 pcs</p> <p style="text-align: center; background-color: #e91e63; color: white; padding: 2px; font-weight: bold; font-size: 10px;">RFQ</p> </div>	<div style="border: 1px solid #ccc; padding: 5px;"> <p style="margin: 0;">CPS16-LA00A10-SNCSNCF-RI0YLVAR-W1075-S</p> <p style="font-size: 8px; margin: 0;">Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 5007 pcs</p> <p style="text-align: center; background-color: #e91e63; color: white; padding: 2px; font-weight: bold; font-size: 10px;">RFQ</p> </div>
<div style="border: 1px solid #ccc; padding: 5px;"> <p style="margin: 0;">CPS16-LA00A10-SNCSNCF-RI0YMMVAR-W1002-S</p> <p style="font-size: 8px; margin: 0;">Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 5165 pcs</p> <p style="text-align: center; background-color: #e91e63; color: white; padding: 2px; font-weight: bold; font-size: 10px;">RFQ</p> </div>	<div style="border: 1px solid #ccc; padding: 5px;"> <p style="margin: 0;">CPS16-LA00A10-SNCSNCF-RI0YLVAR-W1073-S</p> <p style="font-size: 8px; margin: 0;">Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 5169 pcs</p> <p style="text-align: center; background-color: #e91e63; color: white; padding: 2px; font-weight: bold; font-size: 10px;">RFQ</p> </div>