

Schurter

ELECTRONIC COMPONE

CPS19-LA00A10-SNCCWTNF-AI0GRVAR-W1011-S

Tau Wae:	CPS19-LA00A10-SNCCWTNF-AI0GRVAR-W1011-S
Kaihanga / Waitohu:	Schurter
Whakaahuatanga hua	SWITCH PUSHBUTTON SPST 100MA 42V
Ngā Rauemi:	CPS19-LA00A10-SNCCWTNF-AI0GRVAR-W1011-S.pdf
RoHS Tūnga	Whakahaerehia te kore utu / RoHS
Waehe Stock	6453 pcs stock
Tuhinga mai i	Hong Kong
Te Ara Tuhi	DHL/Fedex/TNT/UPS/EMS

TONO MO TE WHAKAHUA

Ko te whakaahua he tohu. Tirohia nga korero mo nga taipitopito hua.

Ngā whakaaturanga o CPS19-LA00A10-SNCCWTNF-AI0GRVAR-W1011-S

TAU WAE	CPS19-LA00A10-SNCCWTNF-AI0GRVAR-W1011-S
KAIHANGA	Schurter
WHAKAAHUATANGA	SWITCH PUSHBUTTON SPST 100MA 42V
WHAKAHAERE TOKO WHAKAHAERE / ROHS TŪNGA	Whakahaerehia te kore utu / RoHS
HE RAHINGA KEI TE WĀTEA	6453 pcs
PEPA RARAUNGA	CPS19-LA00A10-SNCCWTNF-AI0GRVAR-W1011-S.pdf
WHAKAAETANGA NGAOHIKO - DC	60V
WHAKAAETANGA NGAOHIKO - AC	42V
MOMO	Capacitive, Illuminated
KĀHUA WHAKAMUTUNGA	Wire Leads
WHAKAWHITI MAHINGA	Off-On
RAUPAPA	CPS
PIHANGA WHAKAPAE PAEPAE	Circular - 19.10mm Dia
PACKAGING	Bulk
TAE MAHI	-40°C ~ 60°C
MOMO TAE	Panel Mount, Front
TAUMATA WHAKAARO MOE (MSL)	1 (Unlimited)
TE MAHI MOMO	-
WHAKAHAERE TOKO WHAKAHAERE / ROHS TŪNGA	Lead free / RoHS Compliant
TIAKI INGOA	IP67 - Dust Tight, Waterproof
WHAKAKAMAHI WHAKAKUKU (NOMINAL)	5 ~ 28 VDC
MOMO WHAKAMARAMA, TAE	LED, Green/Red
NGĀ ĀHUATANGA	Ceramic Actuator, K Symbol
TE ORANGA RAWA	-
WHAKAAHUATANGA TAIPITOPITO	Pushbutton Switch SPST Capacitive, Illuminated Panel Mount, Front
WHAKATAURANGA ONAMATA	100mA (AC/DC)
TAE - KAIHOAHOA / KAPORO	Clear (White Filter/Diffuser)
TAKAHANGA	SPST
MOMO KAIHOKO	Round, Button, Flush

Ngā tūtohu e hāngai ana

Schurter CPS19-LA00A10-SNCCWTNF-AI0GRVAR-W1011-S	CPS19-LA00A10-SNCCWTNF-AI0GRVAR-W1011-S Kaihiwhi	CPS19-LA00A10-SNCCWTNF-AI0GRVAR-W1011-S Kaiwhakarato
CPS19-LA00A10-SNCCWTNF-AI0GRVAR-W1011-S Utu	CPS19-LA00A10-SNCCWTNF-AI0GRVAR-W1011-S Pikitia	CPS19-LA00A10-SNCCWTNF-AI0GRVAR-W1011-S Whakaahua
CPS19-LA00A10-SNCCWTNF-AI0GRVAR-W1011-S PDF Datasheet	CPS19-LA00A10-SNCCWTNF-AI0GRVAR-W1011-S Download Datasheet	Tuhinga CPS19-LA00A10-SNCCWTNF-AI0GRVAR-W1011-S
CPS19-LA00A10-SNCCWTNF-AI0GRVAR-W1011-S Stock	Hokona CPS19-LA00A10-SNCCWTNF-AI0GRVAR-W1011-S	Hokona Schurter CPS19-LA00A10-SNCCWTNF-AI0GRVAR-W1011-S
Schurter CPS19-LA00A10-SNCCWTNF-AI0GRVAR-W1011-S	Schurter Kaiwhakarato	Schurter Kaihiwhi
Schurter CPS19-LA00A10-SNCCWTNF-AI0GRVAR-W1011-S	Schurter Inc. CPS19-LA00A10-SNCCWTNF-AI0GRVAR-W1011-S	

Ngā Hua e hāngai ana

<div style="border: 1px solid #ccc; padding: 5px;"> <p style="margin: 0;">CPS19-LA00A10-SNCCWTNF-AI0GRVAR-W1010-S</p> <p style="margin: 0; font-size: 10px;">Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 6056 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 2px; font-weight: bold; font-size: 10px;">RFQ</p> </div>	<div style="border: 1px solid #ccc; padding: 5px;"> <p style="margin: 0;">CPS19-LA00A10-SNCCWTNF-AI0GRVAR-W1009-S</p> <p style="margin: 0; font-size: 10px;">Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 2824 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 2px; font-weight: bold; font-size: 10px;">RFQ</p> </div>
<div style="border: 1px solid #ccc; padding: 5px;"> <p style="margin: 0;">CPS19-LA00A10-SNCCWTNF-AI0GRVAR-W1006-S</p> <p style="margin: 0; font-size: 10px;">Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 3080 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 2px; font-weight: bold; font-size: 10px;">RFQ</p> </div>	<div style="border: 1px solid #ccc; padding: 5px;"> <p style="margin: 0;">CPS19-LA00A10-SNCCWTNF-AI0GRVAR-W1007-S</p> <p style="margin: 0; font-size: 10px;">Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 6827 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 2px; font-weight: bold; font-size: 10px;">RFQ</p> </div>
<div style="border: 1px solid #ccc; padding: 5px;"> <p style="margin: 0;">CPS19-LA00A10-SNCCWTNF-AI0GRVAR-W1005-S</p> <p style="margin: 0; font-size: 10px;">Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 6112 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 2px; font-weight: bold; font-size: 10px;">RFQ</p> </div>	<div style="border: 1px solid #ccc; padding: 5px;"> <p style="margin: 0;">CPS19-LA00A10-SNCCWTNF-AI0GRVAR-W1017-S</p> <p style="margin: 0; font-size: 10px;">Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 4640 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 2px; font-weight: bold; font-size: 10px;">RFQ</p> </div>
<div style="border: 1px solid #ccc; padding: 5px;"> <p style="margin: 0;">CPS19-LA00A10-SNCCWTNF-AI0GRVAR-W1008-S</p> <p style="margin: 0; font-size: 10px;">Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 4763 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 2px; font-weight: bold; font-size: 10px;">RFQ</p> </div>	<div style="border: 1px solid #ccc; padding: 5px;"> <p style="margin: 0;">CPS19-LA00A10-SNCCWTNF-AI0GRVAR-W1014-S</p> <p style="margin: 0; font-size: 10px;">Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 3994 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 2px; font-weight: bold; font-size: 10px;">RFQ</p> </div>
<div style="border: 1px solid #ccc; padding: 5px;"> <p style="margin: 0;">CPS19-LA00A10-SNCCWTNF-AI0GRVAR-W1012-S</p> <p style="margin: 0; font-size: 10px;">Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 6086 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 2px; font-weight: bold; font-size: 10px;">RFQ</p> </div>	<div style="border: 1px solid #ccc; padding: 5px;"> <p style="margin: 0;">CPS19-LA00A10-SNCCWTNF-AI0GRVAR-W1015-S</p> <p style="margin: 0; font-size: 10px;">Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 5396 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 2px; font-weight: bold; font-size: 10px;">RFQ</p> </div>
<div style="border: 1px solid #ccc; padding: 5px;"> <p style="margin: 0;">CPS19-LA00A10-SNCCWTNF-AI0GRVAR-W1013-S</p> <p style="margin: 0; font-size: 10px;">Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 6312 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 2px; font-weight: bold; font-size: 10px;">RFQ</p> </div>	<div style="border: 1px solid #ccc; padding: 5px;"> <p style="margin: 0;">CPS19-LA00A10-SNCCWTNF-AI0GRVAR-W1016-S</p> <p style="margin: 0; font-size: 10px;">Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 5893 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 2px; font-weight: bold; font-size: 10px;">RFQ</p> </div>