

Schurter

CPS19-NC00A10-SNCCWTNF-AI0CBVAR-W1072-S

Tau Wae:	CPS19-NC00A10-SNCCWTNF-AI0CBVAR-W1072-S
Kaihanga / Waitohu:	Schurter
Whakaahuatanga hua	SWITCH PUSH SPST-NC 100MA 42V
Ngā Rauemi:	CPS19-NC00A10-SNCCWTNF-AI0CBVAR-W1072-S.pdf
RoHs Tūnga	Whakahaerehia te kore utu / RoHS
Waehe Stock	5667 pcs stock
Tuhinga mai i	Hong Kong
Te Ara Tuhi	DHL/Fedex/TNT/UPS/EMS

TONO MO TE WHAKAHUA

Ko te whakaahua he tohu. Tirohia nga korero mo nga taipitopito hua.

Ngā whakaaturanga o CPS19-NC00A10-SNCCWTNF-AI0CBVAR-W1072-S

TAU WAE	CPS19-NC00A10-SNCCWTNF-AI0CBVAR-W1072-S
KAIHANGA	Schurter
WHAKAAHUATANGA	SWITCH PUSH SPST-NC 100MA 42V
WHAKAHAERE TOKO WHAKAHAERE / ROHS TŪNGA	Whakahaerehia te kore utu / RoHS
HE RAHINGA KEI TE WĀTEA	5667 pcs
PEPA RARAUNGA	CPS19-NC00A10-SNCCWTNF-AI0CBVAR-W1072-S.pdf
WHAKAAETANGA NGAOHIKO - DC	60V
WHAKAAETANGA NGAOHIKO - AC	42V
MOMO	Capacitive, Illuminated
KĀHUA WHAKAMUTUNGA	Wire Leads
WHAKAWHITI MAHINGA	On-Mom
RAUPAPA	CPS
PIHANGA WHAKAPAE PAEPAE	Circular - 19.10mm Dia
PACKAGING	Bulk
TAE MAHI	-40°C ~ 60°C
MOMO TAE	Panel Mount, Front
TAUMATA WHAKAARO MOE (MSL)	1 (Unlimited)
TE MAHI MOMO	-
WHAKAHAERE TOKO WHAKAHAERE / ROHS TŪNGA	Lead free / RoHS Compliant
TIAKI INGOA	IP67 - Dust Tight, Waterproof
WHAKAKAMAHI WHAKAKUKU (NOMINAL)	5 ~ 28 VDC
MOMO WHAKAMARAMA, TAE	LED, Cyan/Blue
NGĀ ĀHUATANGA	Ceramic Actuator, START Symbol
TE ORANGA RAWA	-
WHAKAAHUATANGA TAIPITOPITO	Pushbutton Switch SPST-NC Capacitive, Illuminated Panel Mount, Front
WHAKATAURANGA ONAMATA	100mA (AC/DC)
TAE - KAIHOAHOA / KAPORO	Clear (White Filter/Diffuser)
TAKAHANGA	SPST-NC
MOMO KAIHOKO	Round, Button, Flush

Ngā tūtohu e hāngai ana

Schurter CPS19-NC00A10-SNCCWTNF-AI0CBVAR-W1072-S	CPS19-NC00A10-SNCCWTNF-AI0CBVAR-W1072-S Kaiwhiwhi	CPS19-NC00A10-SNCCWTNF-AI0CBVAR-W1072-S Kaiwhakarato
CPS19-NC00A10-SNCCWTNF-AI0CBVAR-W1072-S Utu	CPS19-NC00A10-SNCCWTNF-AI0CBVAR-W1072-S Pikitia	CPS19-NC00A10-SNCCWTNF-AI0CBVAR-W1072-S Whakaahua
CPS19-NC00A10-SNCCWTNF-AI0CBVAR-W1072-S PDF Datasheet	CPS19-NC00A10-SNCCWTNF-AI0CBVAR-W1072-S Download Datasheet	Tuhinga CPS19-NC00A10-SNCCWTNF-AI0CBVAR-W1072-S
CPS19-NC00A10-SNCCWTNF-AI0CBVAR-W1072-S Stock	Hokona CPS19-NC00A10-SNCCWTNF-AI0CBVAR-W1072-S	Hokona Schurter CPS19-NC00A10-SNCCWTNF-AI0CBVAR-W1072-S
Schurter CPS19-NC00A10-SNCCWTNF-AI0CBVAR-W1072-S	Schurter Kaiwhakarato	Schurter Kaiwhiwhi
Schurter CPS19-NC00A10-SNCCWTNF-AI0CBVAR-W1072-S	Schurter Inc. CPS19-NC00A10-SNCCWTNF-AI0CBVAR-W1072-S	

Ngā Hua e hāngai ana

<p>CPS19-NC00A10-SNCCWTNF-AI0CBVAR-W1070-S</p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NC 100MA 42V I roto i te taonga: 5563 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px;">RFQ</p>	<p>CPS19-NC00A10-SNCCWTNF-AI0CBVAR-W1071-S</p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NC 100MA 42V I roto i te taonga: 3623 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px;">RFQ</p>
<p>CPS19-NC00A10-SNCCWTNF-AI0CEVAR-W0000-S</p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NC 100MA 42V I roto i te taonga: 4381 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px;">RFQ</p>	<p>CPS19-NC00A10-SNCCWTNF-AI0CBVAR-W1069-S</p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NC 100MA 42V I roto i te taonga: 6146 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px;">RFQ</p>
<p>CPS19-NC00A10-SNCCWTNF-AI0CBVAR-W1073-S</p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NC 100MA 42V I roto i te taonga: 6715 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px;">RFQ</p>	<p>CPS19-NC00A10-SNCCWTNF-AI0CBVAR-W1066-S</p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NC 100MA 42V I roto i te taonga: 5673 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px;">RFQ</p>
<p>CPS19-NC00A10-SNCCWTNF-AI0CBVAR-W1076-S</p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NC 100MA 42V I roto i te taonga: 4116 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px;">RFQ</p>	<p>CPS19-NC00A10-SNCCWTNF-AI0CBVAR-W1075-S</p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NC 100MA 42V I roto i te taonga: 6356 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px;">RFQ</p>
<p>CPS19-NC00A10-SNCCWTNF-AI0CBVAR-W1074-S</p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NC 100MA 42V I roto i te taonga: 6673 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px;">RFQ</p>	<p>CPS19-NC00A10-SNCCWTNF-AI0CBVAR-W1068-S</p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NC 100MA 42V I roto i te taonga: 4930 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px;">RFQ</p>
<p>CPS19-NC00A10-SNCCWTNF-AI0CBVAR-W1067-S</p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NC 100MA 42V I roto i te taonga: 3563 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px;">RFQ</p>	<p>CPS19-NC00A10-SNCCWTNF-AI0CBVAR-W1077-S</p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NC 100MA 42V I roto i te taonga: 4160 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px;">RFQ</p>