

Schurter

CPS22-LA00A10-SNCCWTNF-AI0CRVAR-W1003-S

Tau Wae:	CPS22-LA00A10-SNCCWTNF-AI0CRVAR-W1003-S
Kaihanga / Waitohu:	Schurter
Whakaahuatanga hua	SWITCH PUSHBUTTON SPST 100MA 42V
Ngā Rauemi:	CPS22-LA00A10-SNCCWTNF-AI0CRVAR-W1003-S.pdf
RoHs Tūnga	Whakahaerehia te kore utu / RoHS
Waehere Stock	6881 pcs stock
Tuhinga mai i	Hong Kong
Te Ara Tuhi	DHL/Fedex/TNT/UPS/EMS

TONO MO TE WHAKAHUA

Ko te whakaahua he tohu. Tirohia nga korero mo nga taipitopito hua.

Ngā whakaaturanga o CPS22-LA00A10-SNCCWTNF-AI0CRVAR-W1003-S

TAU WAE	CPS22-LA00A10-SNCCWTNF-AI0CRVAR-W1003-S
KAIHANGA	Schurter
WHAKAAHUATANGA	SWITCH PUSHBUTTON SPST 100MA 42V
WHAKAHAERE TOKO WHAKAHAERE / ROHS TŪNGA	Whakahaerehia te kore utu / RoHS
HE RAHINGA KEI TE WĀTEA	6881 pcs
PEPA RARAUNGA	CPS22-LA00A10-SNCCWTNF-AI0CRVAR-W1003-S.pdf
WHAKAAETANGA NGAOHIKO - DC	60V
WHAKAAETANGA NGAOHIKO - AC	42V
MOMO	Capacitive, Illuminated
KĀHUA WHAKAMUTUNGA	Wire Leads
WHAKAWHITI MAHINGA	Off-On
RAUPAPA	CPS
PIHANGA WHAKAPAE PAEPAE	Circular - 22.10mm Dia
PACKAGING	Bulk
TAE MAHI	-40°C ~ 60°C
MOMO TAE	Panel Mount, Front
TAUMATA WHAKAARO MOE (MSL)	1 (Unlimited)
TE MAHI MOMO	-
WHAKAHAERE TOKO WHAKAHAERE / ROHS TŪNGA	Lead free / RoHS Compliant
TIAKI INGOA	IP67 - Dust Tight, Waterproof
WHAKAKAMAHI WHAKAKUKU (NOMINAL)	5 ~ 28 VDC
MOMO WHAKAMARAMA, TAE	LED, Cyan/Red
NGĀ ĀHUATANGA	Ceramic Actuator, C Symbol
TE ORANGA RAWA	-
WHAKAAHUATANGA TAIPITOPITO	Pushbutton Switch SPST Capacitive, Illuminated Panel Mount, Front
WHAKATAURANGA ONAMATA	100mA (AC/DC)
TAE - KAIHOAHOA / KAPORO	Clear (White Filter/Diffuser)
TAKAHANGA	SPST
MOMO KAIHOKO	Round, Button, Flush

Ngā tūtohu e hāngai ana

Schurter CPS22-LA00A10-SNCCWTNF-AI0CRVAR-W1003-S	CPS22-LA00A10-SNCCWTNF-AI0CRVAR-W1003-S Kaihiwhi	CPS22-LA00A10-SNCCWTNF-AI0CRVAR-W1003-S Kaiwhakarato
CPS22-LA00A10-SNCCWTNF-AI0CRVAR-W1003-S Utu	CPS22-LA00A10-SNCCWTNF-AI0CRVAR-W1003-S Pikitia	CPS22-LA00A10-SNCCWTNF-AI0CRVAR-W1003-S Whakaahua
CPS22-LA00A10-SNCCWTNF-AI0CRVAR-W1003-S PDF Datasheet	CPS22-LA00A10-SNCCWTNF-AI0CRVAR-W1003-S Download Datasheet	Tuhinga CPS22-LA00A10-SNCCWTNF-AI0CRVAR-W1003-S
CPS22-LA00A10-SNCCWTNF-AI0CRVAR-W1003-S Stock	Hokona CPS22-LA00A10-SNCCWTNF-AI0CRVAR-W1003-S	Hokona Schurter CPS22-LA00A10-SNCCWTNF-AI0CRVAR-W1003-S
Schurter CPS22-LA00A10-SNCCWTNF-AI0CRVAR-W1003-S	Schurter Kaiwhakarato	Schurter Kaihiwhi
Schurter CPS22-LA00A10-SNCCWTNF-AI0CRVAR-W1003-S	Schurter Inc. CPS22-LA00A10-SNCCWTNF-AI0CRVAR-W1003-S	

Ngā Hua e hāngai ana

<p>CPS22-LA00A10-SNCCWTNF-AI0CRVAR-W1009-S Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 2969 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 2px;">RFQ</p>	<p>CPS22-LA00A10-SNCCWTNF-AI0CMVAR-W1076-S Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 4953 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 2px;">RFQ</p>
<p>CPS22-LA00A10-SNCCWTNF-AI0CMVAR-W1075-S Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 2706 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 2px;">RFQ</p>	<p>CPS22-LA00A10-SNCCWTNF-AI0CRVAR-W1006-S Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 4218 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 2px;">RFQ</p>
<p>CPS22-LA00A10-SNCCWTNF-AI0CRVAR-W0000-S Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 5518 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 2px;">RFQ</p>	<p>CPS22-LA00A10-SNCCWTNF-AI0CRVAR-W1004-S Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 3852 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 2px;">RFQ</p>
<p>CPS22-LA00A10-SNCCWTNF-AI0CRVAR-W1001-S Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 3922 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 2px;">RFQ</p>	<p>CPS22-LA00A10-SNCCWTNF-AI0CRVAR-W1002-S Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 2863 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 2px;">RFQ</p>
<p>CPS22-LA00A10-SNCCWTNF-AI0CRVAR-W1007-S Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 3595 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 2px;">RFQ</p>	<p>CPS22-LA00A10-SNCCWTNF-AI0CRVAR-W1005-S Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 5316 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 2px;">RFQ</p>
<p>CPS22-LA00A10-SNCCWTNF-AI0CRVAR-W1008-S Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 4041 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 2px;">RFQ</p>	<p>CPS22-LA00A10-SNCCWTNF-AI0CMVAR-W1077-S Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 6384 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 2px;">RFQ</p>