

**Schurter**

## CPS22-LA00A10-SNCSNCWF-RI0MCMVAR-W1045-S

Tau Wae:	CPS22-LA00A10-SNCSNCWF-RI0MCMVAR-W1045-S
Kaihanga / Waitohu:	Schurter
Whakaahuatanga hua	SWITCH PUSHBUTTON SPST 100MA 42V
Ngā Rauemi:	CPS22-LA00A10-SNCSNCWF-RI0MCMVAR-W1045-S.pdf
RoHS Tūnga	Whakahaerehia te kore utu / RoHS
Waehe Stock	5966 pcs stock
Tuhinga mai i	Hong Kong
Te Ara Tuhi	DHL/Fedex/TNT/UPS/EMS

TONO MO TE WHAKAHUA

Ko te whakaahua he tohu. Tirohia nga korero mo nga taipitopito hua.

## Ngā whakaaturanga o CPS22-LA00A10-SNCSNCWF-RI0MCMVAR-W1045-S

TAU WAE	CPS22-LA00A10-SNCSNCWF-RI0MCMVAR-W1045-S
KAIHANGA	Schurter
WHAKAAHUATANGA	SWITCH PUSHBUTTON SPST 100MA 42V
WHAKAHAERE TOKO WHAKAHAERE / ROHS TŪNGA	Whakahaerehia te kore utu / RoHS
HE RAHINGA KEI TE WĀTEA	5966 pcs
PEPA RARAUNGA	CPS22-LA00A10-SNCSNCWF-RI0MCMVAR-W1045-S.pdf
WHAKAAETANGA NGAOHIKO - DC	60V
WHAKAAETANGA NGAOHIKO - AC	42V
MOMO	Capacitive, Illuminated
KĀHUA WHAKAMUTUNGA	Wire Leads
WHAKAWHITI MAHINGA	Off-On
RAUPAPA	CPS
PIHANGA WHAKAPAE PAEPAE	Circular - 22.10mm Dia
PACKAGING	Bulk
TAE MAHI	-40°C ~ 60°C
MOMO TAE	Panel Mount, Front
TAUMATA WHAKAARO MOE (MSL)	1 (Unlimited)
TE MAHI MOMO	-
WHAKAHAERE TOKO WHAKAHAERE / ROHS TŪNGA	Lead free / RoHS Compliant
TIAKI INGOA	IP67 - Dust Tight, Waterproof
WHAKAKAMAHI WHAKAKUKU (NOMINAL)	5 ~ 28 VDC
MOMO WHAKAMARAMA, TAE	LED, Magenta/Cyan
NGĀ ĀHUATANGA	Finger Guide, Arrow Symbol
TE ORANGA RAWA	-
WHAKAAHUATANGA TAIPITOPITO	Pushbutton Switch SPST Capacitive, Illuminated Panel Mount, Front
WHAKATAURANGA ONAMATA	100mA (AC/DC)
TAE - KAIHOAHOA / KAPORO	Silver
TAKAHANGA	SPST
MOMO KAIHOKO	Round, Button, Flush

### Ngā tūtohu e hāngai ana

Schurter CPS22-LA00A10-SNCSNCWF-RI0MCMVAR-W1045-S	CPS22-LA00A10-SNCSNCWF-RI0MCMVAR-W1045-S Kaiwhiwhi	CPS22-LA00A10-SNCSNCWF-RI0MCMVAR-W1045-S Kaiwhakarato
CPS22-LA00A10-SNCSNCWF-RI0MCMVAR-W1045-S Utu	CPS22-LA00A10-SNCSNCWF-RI0MCMVAR-W1045-S Pikitia	CPS22-LA00A10-SNCSNCWF-RI0MCMVAR-W1045-S Whakaahua
CPS22-LA00A10-SNCSNCWF-RI0MCMVAR-W1045-S PDF Datasheet	CPS22-LA00A10-SNCSNCWF-RI0MCMVAR-W1045-S Download Datasheet	Tuhinga CPS22-LA00A10-SNCSNCWF-RI0MCMVAR-W1045-S
CPS22-LA00A10-SNCSNCWF-RI0MCMVAR-W1045-S Stock	Hokona CPS22-LA00A10-SNCSNCWF-RI0MCMVAR-W1045-S	Hokona Schurter CPS22-LA00A10-SNCSNCWF-RI0MCMVAR-W1045-S
Schurter CPS22-LA00A10-SNCSNCWF-RI0MCMVAR-W1045-S	Schurter Kaiwhakarato	Schurter Kaiwhiwhi
Schurter CPS22-LA00A10-SNCSNCWF-RI0MCMVAR-W1045-S	Schurter Inc. CPS22-LA00A10-SNCSNCWF-RI0MCMVAR-W1045-S	

### Ngā Hua e hāngai ana

<p><b>CPS22-LA00A10-SNCSNCWF-RI0MCMVAR-W1044-S</b></p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 3868 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px; font-weight: bold;">RFQ</p>	<p><b>CPS22-LA00A10-SNCSNCWF-RI0MCMVAR-W1043-S</b></p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 6600 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px; font-weight: bold;">RFQ</p>
<p><b>CPS22-LA00A10-SNCSNCWF-RI0MCMVAR-W1051-S</b></p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 5712 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px; font-weight: bold;">RFQ</p>	<p><b>CPS22-LA00A10-SNCSNCWF-RI0MCMVAR-W1049-S</b></p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 3462 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px; font-weight: bold;">RFQ</p>
<p><b>CPS22-LA00A10-SNCSNCWF-RI0MCMVAR-W1046-S</b></p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 5398 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px; font-weight: bold;">RFQ</p>	<p><b>CPS22-LA00A10-SNCSNCWF-RI0MCMVAR-W1042-S</b></p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 5245 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px; font-weight: bold;">RFQ</p>
<p><b>CPS22-LA00A10-SNCSNCWF-RI0MCMVAR-W1041-S</b></p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 6542 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px; font-weight: bold;">RFQ</p>	<p><b>CPS22-LA00A10-SNCSNCWF-RI0MCMVAR-W1047-S</b></p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 6126 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px; font-weight: bold;">RFQ</p>
<p><b>CPS22-LA00A10-SNCSNCWF-RI0MCMVAR-W1050-S</b></p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 5963 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px; font-weight: bold;">RFQ</p>	<p><b>CPS22-LA00A10-SNCSNCWF-RI0MCMVAR-W1039-S</b></p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 4024 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px; font-weight: bold;">RFQ</p>
<p><b>CPS22-LA00A10-SNCSNCWF-RI0MCMVAR-W1048-S</b></p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 4199 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px; font-weight: bold;">RFQ</p>	<p><b>CPS22-LA00A10-SNCSNCWF-RI0MCMVAR-W1040-S</b></p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 5044 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px; font-weight: bold;">RFQ</p>