

Schurter

CPS19-NO00A10-SNCCWTNF-AI0BWWAR-W1034-S

Tau Wae:	CPS19-NO00A10-SNCCWTNF-AI0BWWAR-W1034-S
Kaihanga / Waitohu:	Schurter
Whakaahuatanga hua	SWITCH PUSH SPST-NO 100MA 42V
Ngā Rauemi:	CPS19-NO00A10-SNCCWTNF-AI0BWWAR-W1034-S.pdf
RoHS Tūnga	Whakahaerehia te kore utu / RoHS
Waehe Stock	6535 pcs stock
Tuhinga mai i	Hong Kong
Te Ara Tuhi	DHL/Fedex/TNT/UPS/EMS

TONO MO TE WHAKAHUA

Ko te whakaahua he tohu. Tirohia nga korero mo nga taipitopito hua.

Ngā whakaaturanga o CPS19-NO00A10-SNCCWTNF-AI0BWWAR-W1034-S

TAU WAE	CPS19-NO00A10-SNCCWTNF-AI0BWWAR-W1034-S
KAIHANGA	Schurter
WHAKAAHUATANGA	SWITCH PUSH SPST-NO 100MA 42V
WHAKAHAERE TOKO WHAKAHAERE / ROHS TŪNGA	Whakahaerehia te kore utu / RoHS
HE RAHINGA KEI TE WĀTEA	6535 pcs
PEPA RARAUNGA	CPS19-NO00A10-SNCCWTNF-AI0BWWAR-W1034-S.pdf
WHAKAAETANGA NGAOHIKO - DC	60V
WHAKAAETANGA NGAOHIKO - AC	42V
MOMO	Capacitive, Illuminated
KĀHUA WHAKAMUTUNGA	Wire Leads
WHAKAWHITI MAHINGA	Off-Mom
RAUPAPA	CPS
PIHANGA WHAKAPAE PAEPAE	Circular - 19.10mm Dia
PACKAGING	Bulk
TAE MAHI	-40°C ~ 60°C
MOMO TAE	Panel Mount, Front
TAUMATA WHAKAARO MOE (MSL)	1 (Unlimited)
TE MAHI MOMO	-
WHAKAHAERE TOKO WHAKAHAERE / ROHS TŪNGA	Lead free / RoHS Compliant
TIAKI INGOA	IP67 - Dust Tight, Waterproof
WHAKAKAMAHI WHAKAKUKU (NOMINAL)	5 ~ 28 VDC
MOMO WHAKAMARAMA, TAE	LED, Blue/White
NGĀ ĀHUATANGA	Ceramic Actuator, 7 Symbol
TE ORANGA RAWA	-
WHAKAAHUATANGA TAIPITOPITO	Pushbutton Switch SPST-NO Capacitive, Illuminated Panel Mount, Front
WHAKATAURANGA ONAMATA	100mA (AC/DC)
TAE - KAIHOAHOA / KAPORO	Clear (White Filter/Diffuser)
TAKAHANGA	SPST-NO
MOMO KAIHOKO	Round, Button, Flush

Ngā tūtohu e hāngai ana

Schurter CPS19-NO00A10-SNCCWTNF-AI0BWWAR-W1034-S	CPS19-NO00A10-SNCCWTNF-AI0BWWAR-W1034-S Kaiwhiwhi	CPS19-NO00A10-SNCCWTNF-AI0BWWAR-W1034-S Kaiwhakarato
CPS19-NO00A10-SNCCWTNF-AI0BWWAR-W1034-S Utu	CPS19-NO00A10-SNCCWTNF-AI0BWWAR-W1034-S Pikitia	CPS19-NO00A10-SNCCWTNF-AI0BWWAR-W1034-S Whakaahua
CPS19-NO00A10-SNCCWTNF-AI0BWWAR-W1034-S PDF Datasheet	CPS19-NO00A10-SNCCWTNF-AI0BWWAR-W1034-S Download Datasheet	Tuhinga CPS19-NO00A10-SNCCWTNF-AI0BWWAR-W1034-S
CPS19-NO00A10-SNCCWTNF-AI0BWWAR-W1034-S Stock	Hokona CPS19-NO00A10-SNCCWTNF-AI0BWWAR-W1034-S	Hokona Schurter CPS19-NO00A10-SNCCWTNF-AI0BWWAR-W1034-S
Schurter CPS19-NO00A10-SNCCWTNF-AI0BWWAR-W1034-S	Schurter Kaiwhakarato	Schurter Kaiwhiwhi
Schurter CPS19-NO00A10-SNCCWTNF-AI0BWWAR-W1034-S	Schurter Inc. CPS19-NO00A10-SNCCWTNF-AI0BWWAR-W1034-S	

Ngā Hua e hāngai ana

<p>CPS19-NO00A10-SNCCWTNF-AI0BWWAR-W1039-S Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NO 100MA 42V I roto i te taonga: 4962 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px;">RFQ</p>	<p>CPS19-NO00A10-SNCCWTNF-AI0BWWAR-W1036-S Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NO 100MA 42V I roto i te taonga: 5788 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px;">RFQ</p>
<p>CPS19-NO00A10-SNCCWTNF-AI0BWWAR-W1038-S Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NO 100MA 42V I roto i te taonga: 4011 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px;">RFQ</p>	<p>CPS19-NO00A10-SNCCWTNF-AI0BWWAR-W1037-S Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NO 100MA 42V I roto i te taonga: 5350 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px;">RFQ</p>
<p>CPS19-NO00A10-SNCCWTNF-AI0BWWAR-W1028-S Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NO 100MA 42V I roto i te taonga: 4176 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px;">RFQ</p>	<p>CPS19-NO00A10-SNCCWTNF-AI0BWWAR-W1035-S Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NO 100MA 42V I roto i te taonga: 5794 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px;">RFQ</p>
<p>CPS19-NO00A10-SNCCWTNF-AI0BWWAR-W1031-S Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NO 100MA 42V I roto i te taonga: 3661 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px;">RFQ</p>	<p>CPS19-NO00A10-SNCCWTNF-AI0BWWAR-W1030-S Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NO 100MA 42V I roto i te taonga: 5952 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px;">RFQ</p>
<p>CPS19-NO00A10-SNCCWTNF-AI0BWWAR-W1029-S Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NO 100MA 42V I roto i te taonga: 5269 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px;">RFQ</p>	<p>CPS19-NO00A10-SNCCWTNF-AI0BWWAR-W1040-S Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NO 100MA 42V I roto i te taonga: 4589 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px;">RFQ</p>
<p>CPS19-NO00A10-SNCCWTNF-AI0BWWAR-W1032-S Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NO 100MA 42V I roto i te taonga: 6112 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px;">RFQ</p>	<p>CPS19-NO00A10-SNCCWTNF-AI0BWWAR-W1033-S Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NO 100MA 42V I roto i te taonga: 3166 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px;">RFQ</p>