

Schurter

CPS16-LA00A10-SNCCWTNF-AIOCEVAR-W1026-S

Tau Wae:	CPS16-LA00A10-SNCCWTNF-AIOCEVAR-W1026-S
Kaihanga / Waitohu:	Schurter
Whakaahuatanga hua	SWITCH PUSHBUTTON SPST 100MA 42V
Ngā Rauemi:	CPS16-LA00A10-SNCCWTNF-AIOCEVAR-W1026-S.pdf
RoHs Tūnga	Whakahaerehia te kore utu / RoHS
Waehe Stock	6527 pcs stock
Tuhinga mai i	Hong Kong
Te Ara Tuhi	DHL/Fedex/TNT/UPS/EMS

TONO MO TE WHAKAHUA

Ko te whakaahua he tohu. Tirohia nga korero mo nga taipitopito hua.

Ngā whakaaturanga o CPS16-LA00A10-SNCCWTNF-AIOCEVAR-W1026-S

TAU WAE	CPS16-LA00A10-SNCCWTNF-AIOCEVAR-W1026-S
KAIHANGA	Schurter
WHAKAAHUATANGA	SWITCH PUSHBUTTON SPST 100MA 42V
WHAKAHAERE TOKO WHAKAHAERE / ROHS TŪNGA	Whakahaerehia te kore utu / RoHS
HE RAHINGA KEI TE WĀTEA	6527 pcs
PEPA RARAUNGA	CPS16-LA00A10-SNCCWTNF-AIOCEVAR-W1026-S.pdf
WHAKAAETANGA NGAOHIKO - DC	60V
WHAKAAETANGA NGAOHIKO - AC	42V
MOMO	Capacitive, Illuminated
KĀHUA WHAKAMUTUNGA	Wire Leads
WHAKAWHITI MAHINGA	Off-On
RAUPAPA	CPS
PIHANGA WHAKAPAE PAEPAE	Circular - 16.10mm Dia
PACKAGING	Bulk
TAE MAHI	-40°C ~ 60°C
MOMO TAE	Panel Mount, Front
TAUMATA WHAKAARO MOE (MSL)	1 (Unlimited)
TE MAHI MOMO	-
WHAKAHAERE TOKO WHAKAHAERE / ROHS TŪNGA	Lead free / RoHS Compliant
TIAKI INGOA	IP67 - Dust Tight, Waterproof
WHAKAKAMAHI WHAKAKUKU (NOMINAL)	5 ~ 28 VDC
MOMO WHAKAMARAMA, TAE	LED, Cyan/Yellow
NGĀ ĀHUATANGA	Ceramic Actuator, Z Symbol
TE ORANGA RAWA	-
WHAKAAHUATANGA TAIPITOPITO	Pushbutton Switch SPST Capacitive, Illuminated Panel Mount, Front
WHAKATAURANGA ONAMATA	100mA (AC/DC)
TAE - KAIHOAHOA / KAPORO	Clear (White Filter/Diffuser)
TAKAHANGA	SPST
MOMO KAIHOKO	Round, Button, Flush

Ngā tūtohu e hāngai ana

Schurter CPS16-LA00A10-SNCCWTNF-AIOCEVAR-W1026-S	CPS16-LA00A10-SNCCWTNF-AIOCEVAR-W1026-S Kaihiwhi	CPS16-LA00A10-SNCCWTNF-AIOCEVAR-W1026-S Kaiwhakarato
CPS16-LA00A10-SNCCWTNF-AIOCEVAR-W1026-S Utu	CPS16-LA00A10-SNCCWTNF-AIOCEVAR-W1026-S Pikitia	CPS16-LA00A10-SNCCWTNF-AIOCEVAR-W1026-S Whakaahua
CPS16-LA00A10-SNCCWTNF-AIOCEVAR-W1026-S PDF Datasheet	CPS16-LA00A10-SNCCWTNF-AIOCEVAR-W1026-S Download Datasheet	Tuhinga CPS16-LA00A10-SNCCWTNF-AIOCEVAR-W1026-S
CPS16-LA00A10-SNCCWTNF-AIOCEVAR-W1026-S Stock	Hokona CPS16-LA00A10-SNCCWTNF-AIOCEVAR-W1026-S	Hokona Schurter CPS16-LA00A10-SNCCWTNF-AIOCEVAR-W1026-S
Schurter CPS16-LA00A10-SNCCWTNF-AIOCEVAR-W1026-S	Schurter Kaiwhakarato	Schurter Kaihiwhi
Schurter CPS16-LA00A10-SNCCWTNF-AIOCEVAR-W1026-S	Schurter Inc. CPS16-LA00A10-SNCCWTNF-AIOCEVAR-W1026-S	

Ngā Hua e hāngai ana

<p>CPS16-LA00A10-SNCCWTNF-AIOCEVAR-W1025-S</p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 4432 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px; font-weight: bold;">RFQ</p>	<p>CPS16-LA00A10-SNCCWTNF-AIOCEVAR-W1024-S</p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 4222 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px; font-weight: bold;">RFQ</p>
<p>CPS16-LA00A10-SNCCWTNF-AIOCEVAR-W1028-S</p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 3515 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px; font-weight: bold;">RFQ</p>	<p>CPS16-LA00A10-SNCCWTNF-AIOCEVAR-W1022-S</p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 6799 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px; font-weight: bold;">RFQ</p>
<p>CPS16-LA00A10-SNCCWTNF-AIOCEVAR-W1027-S</p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 5447 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px; font-weight: bold;">RFQ</p>	<p>CPS16-LA00A10-SNCCWTNF-AIOCEVAR-W1021-S</p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 6355 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px; font-weight: bold;">RFQ</p>
<p>CPS16-LA00A10-SNCCWTNF-AIOCEVAR-W1029-S</p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 6959 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px; font-weight: bold;">RFQ</p>	<p>CPS16-LA00A10-SNCCWTNF-AIOCEVAR-W1020-S</p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 4398 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px; font-weight: bold;">RFQ</p>
<p>CPS16-LA00A10-SNCCWTNF-AIOCEVAR-W1031-S</p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 6469 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px; font-weight: bold;">RFQ</p>	<p>CPS16-LA00A10-SNCCWTNF-AIOCEVAR-W1032-S</p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 6400 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px; font-weight: bold;">RFQ</p>
<p>CPS16-LA00A10-SNCCWTNF-AIOCEVAR-W1030-S</p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 5516 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px; font-weight: bold;">RFQ</p>	<p>CPS16-LA00A10-SNCCWTNF-AIOCEVAR-W1023-S</p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 5007 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px; font-weight: bold;">RFQ</p>