

Schurter

CPS19-NO00A10-SNCSNCWF-RI0CEVAR-W1044-S

Tau Wae:	CPS19-NO00A10-SNCSNCWF-RI0CEVAR-W1044-S
Kaihanga / Waitohu:	Schurter
Whakaahuatanga hua	SWITCH PUSH SPST-NO 100MA 42V
Ngā Rauemi:	CPS19-NO00A10-SNCSNCWF-RI0CEVAR-W1044-S.pdf
RoHs Tūnga	Whakahaerehia te kore utu / RoHS
Waehe Stock	4840 pcs stock
Tuhinga mai i	Hong Kong
Te Ara Tuhi	DHL/Fedex/TNT/UPS/EMS

TONO MO TE WHAKAHUA

Ko te whakaahua he tohu. Tirohia nga korero mo nga taipitopito hua.

Ngā whakaaturanga o CPS19-NO00A10-SNCSNCWF-RI0CEVAR-W1044-S

TAU WAE	CPS19-NO00A10-SNCSNCWF-RI0CEVAR-W1044-S
KAIHANGA	Schurter
WHAKAAHUATANGA	SWITCH PUSH SPST-NO 100MA 42V
WHAKAHAERE TOKO WHAKAHAERE / ROHS TŪNGA	Whakahaerehia te kore utu / RoHS
HE RAHINGA KEI TE WĀTEA	4840 pcs
PEPA RARAUNGA	CPS19-NO00A10-SNCSNCWF-RI0CEVAR-W1044-S.pdf
WHAKAAETANGA NGAOHIKO - DC	60V
WHAKAAETANGA NGAOHIKO - AC	42V
MOMO	Capacitive, Illuminated
KĀHUA WHAKAMUTUNGA	Wire Leads
WHAKAWHITI MAHINGA	Off-Mom
RAUPAPA	CPS
PIHANGA WHAKAPAE PAEPAE	Circular - 19.10mm Dia
PACKAGING	Bulk
TAE MAHI	-40°C ~ 60°C
MOMO TAE	Panel Mount, Front
TAUMATA WHAKAARO MOE (MSL)	1 (Unlimited)
TE MAHI MOMO	-
WHAKAHAERE TOKO WHAKAHAERE / ROHS TŪNGA	Lead free / RoHS Compliant
TIAKI INGOA	IP67 - Dust Tight, Waterproof
WHAKAKAMAHI WHAKAKUKU (NOMINAL)	5 ~ 28 VDC
MOMO WHAKAMARAMA, TAE	LED, Cyan/Yellow
NGĀ ĀHUATANGA	Finger Guide, Arrow Symbol
TE ORANGA RAWA	-
WHAKAAHUATANGA TAIPITOPITO	Pushbutton Switch SPST-NO Capacitive, Illuminated Panel Mount, Front
WHAKATAURANGA ONAMATA	100mA (AC/DC)
TAE - KAIHOAHOA / KAPORO	Silver
TAKAHANGA	SPST-NO
MOMO KAIHOKO	Round, Button, Flush

Ngā tūtohu e hāngai ana

Schurter CPS19-NO00A10-SNCSNCWF-RI0CEVAR-W1044-S	CPS19-NO00A10-SNCSNCWF-RI0CEVAR-W1044-S Kaiwhiwhi	CPS19-NO00A10-SNCSNCWF-RI0CEVAR-W1044-S Kaiwhakarato
CPS19-NO00A10-SNCSNCWF-RI0CEVAR-W1044-S Utu	CPS19-NO00A10-SNCSNCWF-RI0CEVAR-W1044-S Pikitia	CPS19-NO00A10-SNCSNCWF-RI0CEVAR-W1044-S Whakaahua
CPS19-NO00A10-SNCSNCWF-RI0CEVAR-W1044-S PDF Datasheet	CPS19-NO00A10-SNCSNCWF-RI0CEVAR-W1044-S Download Datasheet	Tuhinga CPS19-NO00A10-SNCSNCWF-RI0CEVAR-W1044-S
CPS19-NO00A10-SNCSNCWF-RI0CEVAR-W1044-S Stock	Hokona CPS19-NO00A10-SNCSNCWF-RI0CEVAR-W1044-S	Hokona Schurter CPS19-NO00A10-SNCSNCWF-RI0CEVAR-W1044-S
Schurter CPS19-NO00A10-SNCSNCWF-RI0CEVAR-W1044-S	Schurter Kaiwhakarato	Schurter Kaiwhiwhi
Schurter CPS19-NO00A10-SNCSNCWF-RI0CEVAR-W1044-S	Schurter Inc. CPS19-NO00A10-SNCSNCWF-RI0CEVAR-W1044-S	

Ngā Hua e hāngai ana

<p>CPS19-NO00A10-SNCSNCWF-RI0CEVAR-W1046-S Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NO 100MA 42V I roto i te taonga: 4146 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px;">RFQ</p>	<p>CPS19-NO00A10-SNCSNCWF-RI0CEVAR-W1050-S Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NO 100MA 42V I roto i te taonga: 5986 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px;">RFQ</p>
<p>CPS19-NO00A10-SNCSNCWF-RI0CEVAR-W1048-S Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NO 100MA 42V I roto i te taonga: 7046 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px;">RFQ</p>	<p>CPS19-NO00A10-SNCSNCWF-RI0CEVAR-W1043-S Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NO 100MA 42V I roto i te taonga: 5835 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px;">RFQ</p>
<p>CPS19-NO00A10-SNCSNCWF-RI0CEVAR-W1049-S Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NO 100MA 42V I roto i te taonga: 6163 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px;">RFQ</p>	<p>CPS19-NO00A10-SNCSNCWF-RI0CEVAR-W1042-S Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NO 100MA 42V I roto i te taonga: 6254 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px;">RFQ</p>
<p>CPS19-NO00A10-SNCSNCWF-RI0CEVAR-W1045-S Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NO 100MA 42V I roto i te taonga: 3790 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px;">RFQ</p>	<p>CPS19-NO00A10-SNCSNCWF-RI0CEVAR-W1038-S Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NO 100MA 42V I roto i te taonga: 5616 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px;">RFQ</p>
<p>CPS19-NO00A10-SNCSNCWF-RI0CEVAR-W1041-S Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NO 100MA 42V I roto i te taonga: 6528 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px;">RFQ</p>	<p>CPS19-NO00A10-SNCSNCWF-RI0CEVAR-W1047-S Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NO 100MA 42V I roto i te taonga: 6570 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px;">RFQ</p>
<p>CPS19-NO00A10-SNCSNCWF-RI0CEVAR-W1040-S Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NO 100MA 42V I roto i te taonga: 5453 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px;">RFQ</p>	<p>CPS19-NO00A10-SNCSNCWF-RI0CEVAR-W1039-S Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NO 100MA 42V I roto i te taonga: 3022 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px;">RFQ</p>