

**Schurter**

## CPS16-LA00A10-SNCCWTNF-AIOCEVAR-W1031-S

Tau Wae:	<a href="#">CPS16-LA00A10-SNCCWTNF-AIOCEVAR-W1031-S</a>
Kaihanga / Waitohu:	<a href="#">Schurter</a>
Whakaahuatanga hua	SWITCH PUSHBUTTON SPST 100MA 42V
Ngā Rauemi:	<a href="#">CPS16-LA00A10-SNCCWTNF-AIOCEVAR-W1031-S.pdf</a>
RoHs Tūnga	Whakahaerehia te kore utu / RoHS
Waehe Stock	6469 pcs stock
Tuhinga mai i	Hong Kong
Te Ara Tuhi	DHL/Fedex/TNT/UPS/EMS

TONO MO TE WHAKAHUA

Ko te whakaahua he tohu. Tirohia nga korero mo nga taipitopito hua.

### Ngā whakaaturanga o CPS16-LA00A10-SNCCWTNF-AIOCEVAR-W1031-S

TAU WAE	CPS16-LA00A10-SNCCWTNF-AIOCEVAR-W1031-S
KAIHANGA	Schurter
WHAKAAHUATANGA	SWITCH PUSHBUTTON SPST 100MA 42V
WHAKAHAERE TOKO WHAKAHAERE / ROHS TŪNGA	Whakahaerehia te kore utu / RoHS
HE RAHINGA KEI TE WĀTEA	6469 pcs
PEPA RARAUNGA	<a href="#">CPS16-LA00A10-SNCCWTNF-AIOCEVAR-W1031-S.pdf</a>
WHAKAAETANGA NGAOHIKO - DC	60V
WHAKAAETANGA NGAOHIKO - AC	42V
MOMO	Capacitive, Illuminated
KĀHUA WHAKAMUTUNGA	Wire Leads
WHAKAWHITI MAHINGA	Off-On
RAUPAPA	CPS
PIHANGA WHAKAPAE PAEPAE	Circular - 16.10mm Dia
PACKAGING	Bulk
TAE MAHI	-40°C ~ 60°C
MOMO TAE	Panel Mount, Front
TAUMATA WHAKAARO MOE (MSL)	1 (Unlimited)
TE MAHI MOMO	-
WHAKAHAERE TOKO WHAKAHAERE / ROHS TŪNGA	Lead free / RoHS Compliant
TIAKI INGOA	IP67 - Dust Tight, Waterproof
WHAKAKAMAHI WHAKAKUKU (NOMINAL)	5 ~ 28 VDC
MOMO WHAKAMARAMA, TAE	LED, Cyan/Yellow
NGĀ ĀHUATANGA	Ceramic Actuator, 4 Symbol
TE ORANGA RAWA	-
WHAKAAHUATANGA TAIPITOPITO	Pushbutton Switch SPST Capacitive, Illuminated Panel Mount, Front
WHAKATAURANGA ONAMATA	100mA (AC/DC)
TAE - KAIHOAHOA / KAPORO	Clear (White Filter/Diffuser)
TAKAHANGA	SPST
MOMO KAIHOKO	Round, Button, Flush

### Ngā tūtohu e hāngai ana

<a href="#">Schurter CPS16-LA00A10-SNCCWTNF-AIOCEVAR-W1031-S</a>	<a href="#">CPS16-LA00A10-SNCCWTNF-AIOCEVAR-W1031-S Kaihiwhi</a>	<a href="#">CPS16-LA00A10-SNCCWTNF-AIOCEVAR-W1031-S Kaiwhakarato</a>
<a href="#">CPS16-LA00A10-SNCCWTNF-AIOCEVAR-W1031-S Utu</a>	<a href="#">CPS16-LA00A10-SNCCWTNF-AIOCEVAR-W1031-S Pikitia</a>	<a href="#">CPS16-LA00A10-SNCCWTNF-AIOCEVAR-W1031-S Whakaahua</a>
<a href="#">CPS16-LA00A10-SNCCWTNF-AIOCEVAR-W1031-S PDF Datasheet</a>	<a href="#">CPS16-LA00A10-SNCCWTNF-AIOCEVAR-W1031-S Download Datasheet</a>	<a href="#">Tuhinga CPS16-LA00A10-SNCCWTNF-AIOCEVAR-W1031-S</a>
<a href="#">CPS16-LA00A10-SNCCWTNF-AIOCEVAR-W1031-S Stock</a>	<a href="#">Hokona CPS16-LA00A10-SNCCWTNF-AIOCEVAR-W1031-S</a>	<a href="#">Hokona Schurter CPS16-LA00A10-SNCCWTNF-AIOCEVAR-W1031-S</a>
<a href="#">Schurter CPS16-LA00A10-SNCCWTNF-AIOCEVAR-W1031-S</a>	<a href="#">Schurter Kaiwhakarato</a>	<a href="#">Schurter Kaihiwhi</a>
<a href="#">Schurter CPS16-LA00A10-SNCCWTNF-AIOCEVAR-W1031-S</a>	<a href="#">Schurter Inc. CPS16-LA00A10-SNCCWTNF-AIOCEVAR-W1031-S</a>	

### Ngā Hua e hāngai ana

<p><b>CPS16-LA00A10-SNCCWTNF-AIOCEVAR-W1028-S</b></p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 3515 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px; font-weight: bold;">RFQ</p>	<p><b>CPS16-LA00A10-SNCCWTNF-AIOCEVAR-W1025-S</b></p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 4432 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px; font-weight: bold;">RFQ</p>
<p><b>CPS16-LA00A10-SNCCWTNF-AIOCEVAR-W1036-S</b></p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 4139 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px; font-weight: bold;">RFQ</p>	<p><b>CPS16-LA00A10-SNCCWTNF-AIOCEVAR-W1035-S</b></p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 4610 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px; font-weight: bold;">RFQ</p>
<p><b>CPS16-LA00A10-SNCCWTNF-AIOCEVAR-W1029-S</b></p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 6959 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px; font-weight: bold;">RFQ</p>	<p><b>CPS16-LA00A10-SNCCWTNF-AIOCEVAR-W1026-S</b></p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 6527 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px; font-weight: bold;">RFQ</p>
<p><b>CPS16-LA00A10-SNCCWTNF-AIOCEVAR-W1030-S</b></p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 5516 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px; font-weight: bold;">RFQ</p>	<p><b>CPS16-LA00A10-SNCCWTNF-AIOCEVAR-W1032-S</b></p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 6400 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px; font-weight: bold;">RFQ</p>
<p><b>CPS16-LA00A10-SNCCWTNF-AIOCEVAR-W1034-S</b></p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 6397 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px; font-weight: bold;">RFQ</p>	<p><b>CPS16-LA00A10-SNCCWTNF-AIOCEVAR-W1037-S</b></p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 6124 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px; font-weight: bold;">RFQ</p>
<p><b>CPS16-LA00A10-SNCCWTNF-AIOCEVAR-W1033-S</b></p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 3151 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px; font-weight: bold;">RFQ</p>	<p><b>CPS16-LA00A10-SNCCWTNF-AIOCEVAR-W1027-S</b></p> <p>Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 5447 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px; font-weight: bold;">RFQ</p>