

Schurter

CPS19-NO00A10-SNCCWTNF-AIOYWVAR-W1060-S

Tau Wae:	CPS19-NO00A10-SNCCWTNF-AIOYWVAR-W1060-S
Kaihanga / Waitohu:	Schurter
Whakaahuatanga hua	SWITCH PUSH SPST-NO 100MA 42V
Ngā Rauemi:	CPS19-NO00A10-SNCCWTNF-AIOYWVAR-W1060-S.pdf
RoHS Tūnga	Whakahaerehia te kore utu / RoHS
Waehe Stock	3302 pcs stock
Tuhinga mai i	Hong Kong
Te Ara Tuhi	DHL/Fedex/TNT/UPS/EMS

TONO MO TE WHAKAHUA

Ko te whakaahua he tohu. Tirohia nga korero mo nga taipitopito hua.

Ngā whakaaturanga o CPS19-NO00A10-SNCCWTNF-AIOYWVAR-W1060-S

TAU WAE	CPS19-NO00A10-SNCCWTNF-AIOYWVAR-W1060-S
KAIHANGA	Schurter
WHAKAAHUATANGA	SWITCH PUSH SPST-NO 100MA 42V
WHAKAHAERE TOKO WHAKAHAERE / ROHS TŪNGA	Whakahaerehia te kore utu / RoHS
HE RAHINGA KEI TE WĀTEA	3302 pcs
PEPA RARAUNGA	CPS19-NO00A10-SNCCWTNF-AIOYWVAR-W1060-S.pdf
WHAKAAETANGA NGAOHIKO - DC	60V
WHAKAAETANGA NGAOHIKO - AC	42V
MOMO	Capacitive, Illuminated
KĀHUA WHAKAMUTUNGA	Wire Leads
WHAKAWHITI MAHINGA	Off-Mom
RAUPAPA	CPS
PIHANGA WHAKAPAE PAEPAE	Circular - 19.10mm Dia
PACKAGING	Bulk
TAE MAHI	-40°C ~ 60°C
MOMO TAE	Panel Mount, Front
TAUMATA WHAKAARO MOE (MSL)	1 (Unlimited)
TE MAHI MOMO	-
WHAKAHAERE TOKO WHAKAHAERE / ROHS TŪNGA	Lead free / RoHS Compliant
TIAKI INGOA	IP67 - Dust Tight, Waterproof
WHAKAKAMAHI WHAKAKUKU (NOMINAL)	5 ~ 28 VDC
MOMO WHAKAMARAMA, TAE	LED, Yellow/White
NGĀ ĀHUATANGA	Ceramic Actuator, LINE Symbol
TE ORANGA RAWA	-
WHAKAAHUATANGA TAIPITOPITO	Pushbutton Switch SPST-NO Capacitive, Illuminated Panel Mount, Front
WHAKATAURANGA ONAMATA	100mA (AC/DC)
TAE - KAIHOAHOA / KAPORO	Clear (White Filter/Diffuser)
TAKAHANGA	SPST-NO
MOMO KAIHOKO	Round, Button, Flush

Ngā tūtohu e hāngai ana

Schurter CPS19-NO00A10-SNCCWTNF-AIOYWVAR-W1060-S	CPS19-NO00A10-SNCCWTNF-AIOYWVAR-W1060-S Kaiwhiwhi	CPS19-NO00A10-SNCCWTNF-AIOYWVAR-W1060-S Kaiwhakarato
CPS19-NO00A10-SNCCWTNF-AIOYWVAR-W1060-S Utu	CPS19-NO00A10-SNCCWTNF-AIOYWVAR-W1060-S Pikitia	CPS19-NO00A10-SNCCWTNF-AIOYWVAR-W1060-S Whakaahua
CPS19-NO00A10-SNCCWTNF-AIOYWVAR-W1060-S PDF Datasheet	CPS19-NO00A10-SNCCWTNF-AIOYWVAR-W1060-S Download Datasheet	Tuhinga CPS19-NO00A10-SNCCWTNF-AIOYWVAR-W1060-S
CPS19-NO00A10-SNCCWTNF-AIOYWVAR-W1060-S Stock	Hokona CPS19-NO00A10-SNCCWTNF-AIOYWVAR-W1060-S	Hokona Schurter CPS19-NO00A10-SNCCWTNF-AIOYWVAR-W1060-S
Schurter CPS19-NO00A10-SNCCWTNF-AIOYWVAR-W1060-S	Schurter Kaiwhakarato	Schurter Kaiwhiwhi
Schurter CPS19-NO00A10-SNCCWTNF-AIOYWVAR-W1060-S	Schurter Inc. CPS19-NO00A10-SNCCWTNF-AIOYWVAR-W1060-S	

Ngā Hua e hāngai ana

<p>CPS19-NO00A10-SNCCWTNF-AIOYWVAR-W1059-S Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NO 100MA 42V I roto i te taonga: 5331 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px; font-weight: bold;">RFQ</p>	<p>CPS19-NO00A10-SNCCWTNF-AIOYWVAR-W1054-S Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NO 100MA 42V I roto i te taonga: 3292 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px; font-weight: bold;">RFQ</p>
<p>CPS19-NO00A10-SNCCWTNF-AIOYWVAR-W1055-S Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NO 100MA 42V I roto i te taonga: 5588 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px; font-weight: bold;">RFQ</p>	<p>CPS19-NO00A10-SNCCWTNF-AIOYWVAR-W1064-S Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NO 100MA 42V I roto i te taonga: 4785 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px; font-weight: bold;">RFQ</p>
<p>CPS19-NO00A10-SNCCWTNF-AIOYWVAR-W1063-S Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NO 100MA 42V I roto i te taonga: 5326 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px; font-weight: bold;">RFQ</p>	<p>CPS19-NO00A10-SNCCWTNF-AIOYWVAR-W1056-S Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NO 100MA 42V I roto i te taonga: 6398 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px; font-weight: bold;">RFQ</p>
<p>CPS19-NO00A10-SNCCWTNF-AIOYWVAR-W1062-S Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NO 100MA 42V I roto i te taonga: 3286 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px; font-weight: bold;">RFQ</p>	<p>CPS19-NO00A10-SNCCWTNF-AIOYWVAR-W1061-S Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NO 100MA 42V I roto i te taonga: 7069 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px; font-weight: bold;">RFQ</p>
<p>CPS19-NO00A10-SNCCWTNF-AIOYWVAR-W1057-S Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NO 100MA 42V I roto i te taonga: 5587 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px; font-weight: bold;">RFQ</p>	<p>CPS19-NO00A10-SNCCWTNF-AIOYWVAR-W1065-S Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NO 100MA 42V I roto i te taonga: 2843 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px; font-weight: bold;">RFQ</p>
<p>CPS19-NO00A10-SNCCWTNF-AIOYWVAR-W1066-S Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NO 100MA 42V I roto i te taonga: 5765 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px; font-weight: bold;">RFQ</p>	<p>CPS19-NO00A10-SNCCWTNF-AIOYWVAR-W1058-S Kaihanga: Schurter Whakaahuatanga: SWITCH PUSH SPST-NO 100MA 42V I roto i te taonga: 3033 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px; font-weight: bold;">RFQ</p>